

## Class Rules Compliance

### RRS 78 COMPLIANCE WITH CLASS RULES; CERTIFICATES

78.1 While a boat is racing, her owner and any other person in charge shall ensure that the boat is maintained to comply with her class rules and that her measurement or rating certificate, if any, remains valid. In addition, the boat shall also comply at other times specified in the class rules, the notice of race or the sailing instructions.

Rule 78 means that competitors, not Regatta Officials / Technical Committee (Measurers), are responsible for ensuring boats and equipment comply with class rules

Please obtain a copy of the Tasar Class Rules, and ensure your boat complies.

<http://www.sailing.org/classesandequipment/TSR.php>

While all the class rules are important, the following key measurements may be checked before and during the event. It is strongly recommended that entrants self check these measurements prior to the event.

- Hull weight correctors fitted - usually around the thwart support post
- Whisker pole length - 2038mm maximum including end fittings
- Forestay measurement - 4140 mm +/- 20mm
- Hounds to deck measurement - 3720mm minimum
- Mainsheet strop length - 240mm minimum
- Shroud pullback travel - 150mm maximum
- Top of jib to hounds fitting - 115mm maximum (Dacron sails only)
- Bow U bolt to forward track end bolt hole (RCB only) - 2130+/- 5mm
- Centrecase padding - as per class rules
- *Centreboard shall be securely fastened to the hull, by lanyard or other effective means so that they remain in the centreboard case when the boat is inverted, as per Australian Sailing Special regulations 3.03.1 (a)*
- Topmast stiffener present - as per class rules
- Topmast supported by sleeve located in bottom mast - as per class rules